

Directions for Crestron touch panel located on podium in courtroom 23A.

WITNESS, PUBLISH, UNPUBLISH, & JURY, PUBLISH, UNPUBLISH

Note: the podium can select to publish or unpublish documentation to the witness box or all 10 jury monitors. Judge's approval is required to publish so make sure judges approval of such publication.

SOURCE SELECT

This feature allows you to select the video source to the outlying plasma monitors, jury monitors, and all other monitors at each table. A near end shot of live camera feed from court room 23A, document camera, DVD, state, defense, A& B tables, laptop projections if connected. Note: source select is available to the podium Crestron display as well as the Judges display. Note power must be turned on to use the document camera and DVD player built into the center podium. Please turn off power to the DVD player and document camera when not in use. Thank you.

For your convenience there are lap top connections at the state, defense, center podium, witness box, tables A & B.

ROOM VOLUME

This is an over all P.A. system volume adjustment and will adjust the DVD/ volume in very gradual increments. Judge has overall P.A. adjustment located on the judges touch screen in very gradual increments.

ELO TOUCH SCREEN MONITORS WITH BOECKELER ANNOTATION

There are 4 touch screen monitors located at state 1, defense1, center podium, and witness box. Directions should be on the monitors. Also a simple diagram is attached on the last page.

LAVALIER AND HAND HELD MICRAPHONES

All wireless microphones are turned on every day trial is in progress and a new 9 volt battery is installed daily. There should be spare 9 volt batteries kept in the podium drawer. NOTE: All wireless microphones will be turned on and MUTED simply look at the bottom of the wireless Lavalier, or hand held microphone and slide the dipswitch to un-mute. It is suggested to mute them while not in use to reduce possible feedback.

PODIUM ROTATION

The podium will rotate 180 degrees from the Beginning position facing the Judges bench then to address the jury box, and finally it stops at the gallery and balcony are usually used for voir dire.